PIRANHA OFFROAD PRODUCTS P/N BT200DS

'Piranha Off Road products are not associated in any way with Toyota Australia or any of its related companies'

To Suit LANDCRUISER 200 SERIES 4.5L V8 Diesel - Sept 2016







PARTS INCLUDED WITH TRAY

- 1 X Tray
- 2 X M6 Countersunk
- 1 X M8 Bolt
- 1 X Special Top Mount
- 2 X J Bolt

- Locate tray behind drivers side headlight, line up two captive nuts with two holes in tray and secure with 2 X M6 counter sunk bolts. Ensure tray is level (Circled)
- 2. Remove radiator cover panel, replace after battery secured.
- 3. Use special top mount to secure battery with J bolts and bolt to front radiator support panel through captive with M8 bolt
- 4. Use factory J bolt mount near air cleaner instead of hole in tray

RECOMMENDED ISOLATOR

DBE140SF or DBE180-SX Ensure, before closing the bonnet that all items fitted have adequate clearance

Oct 2017