



INSTALLATION GUIDE

IRP019

TOYOTA LANDCRUISER V8 70 Series 2007+



- Ironman 4x4 Recovery Points fit to the chassis
- It will take about 20 mins to install, or 10 mins if installed with fitment of bull bar
- Below is a list of required tools for installing your Ironman 4x4 Recovery Points:
 - **13, 17, 19 and 22mm socket**
 - **19mm spanner**

IMPORTANT: Recovery Point installations should only be done by a qualified person and it is the responsibility of this person to ensure correct fitment.

1. Before installation check recovery points are compatible with your vehicle.

2. If fitting to a vehicle with an Ironman 4x4 bull bar already installed; one side at a time, remove all bolts from the outside of the chassis brackets, and the bolt running vertically through the chassis.



3. Position the Recovery Point to the chassis and use 2 x M10 bolts, flat washers and spring washers. Leave loose.



4. Use the M12 long bolt, pass through the chassis vertically through along with the flat washer, spring washer and nut, leave loose.

Using the M14 bolt, flat washers, spring washer and nut secure through the tie down point.



5. Tighten all bolts.