Engineered durability, extreme duty 4x4 performance.



Application:MIP32800-XPB

Fitting Instructions for Mitsubishi MQ Triton 4N15

- 1. Remove tail pipe/muffler assembly from vehicle.
- 2. Remove front intermediate pipe from the DPF (Diesel Particulate Filter) retain the standard bolts from the DPF Flange.
- 3. Fit replacement rubber exhaust hangers.

30:74

- 4. Fit O^2 and exhaust temp sensor plugs to the first intermediate pipe.
- 5. Fit the first intermediate pipe to the DPF Flange using the standard bolts removed previously. Ensure the rotation of the rear facing flange is as pictured in Figure 1.



Figure 1.

- Fit second intermediate pipe to the first intermediate pipe with four M8x1.25x35mm bolts, eight M8 washers and tighten M8x1.25 lock nuts finger tight.
- 7. Fit muffler to rear intermediate pipe with four M8x1.25x35mm bolts, eight M8 flat washers and tighten M8x1.25 lock nuts finger tight.
- 8. Fit tail pipe to vehicle with four M8x1.25x35mm bolts, eight M8 flat washers and tighten M8x1.25 lock nuts finger tight.
- 9. Tighten all bolts and nuts from front to back of vehicle ensuring all flanges are lined up with each other and test for leaks.

NOTE: WE RECOMMEND FITTING THIS PRODUCT EITHER ON A 4 POST HOIST OR ON THE GROUND



A ROCK SOLID REPUTATION



70-84 Miller Street, Epping, Victoria 3076 Phone **(+61 3) 8401 8500** Facsimile (+61 3) 9401 4869

