

### Engineered durability, extreme duty 4x4 performance.



# **Application: TYP44300-XPB**Fitting Instructions for Toyota Land Cruiser 80 Series Wagon

- 1. Remove rear tail pipe from vehicle.
- 2. Remove intermediate pipe from vehicle.
- 3. Remove engine pipe from vehicle.
- 4. Fit exhaust hanger bracket to chassis rail. Refer figure 1.



Figure 1.

- 5. Fit replacement rubber exhaust hangers.
- 6. Fit engine pipe to vehicle inside the chassis rail with four M10x1.25 nuts and four 16mm O/D washers. Refer figure 2.



Figure 2.



#### A ROCK SOLID REPUTATION

70-84 Miller Street, Epping, Victoria 3076 Phone **(+61 3) 8401 8500** Facsimile (+61 3) 9401 4869





## Engineered durability, extreme duty 4x4 performance.



# **Application: TYP44300-XPB**

- 7. Fit o<sup>2</sup> and exhaust temp sensor plugs to engine pipe.
- 8. Fit front intermediate pipe to engine pipe with four M8x1.25x35mm bolts, eight M8 washers and tighten M8x1.25 lock nuts bolts finger tight.
- 9. Fit muffler to front intermediate pipe with four M8x1.25x35mm bolts with eight M8 flat washers tighten M8x1.25 lock nuts finger tight.
- 10. Fit rear intermediate pipe to muffler with four M8x1.25x35mm bolts, eight M8 flat washers and tighten M8x1.25 lock nuts bolts finger tight.
- 11. Fit intermediate tail pipe to rear intermediate pipe using 3" band clamp tighten finger tight. Refer Figure 3.



Figure 3

- 12. Fit tail pipe to intermediate tail pipe with four M8x1.25x35mm bolts and eight M8 flat washers tighten M8x1.25 lock nuts finger tight.
- 13. Tighten all bolts and nuts from front to back of the vehicle and test for leaks.

NOTE: WE RECOMMEND FITTING THIS PRODUCT EITHER ON A 4 POST HOIST OR ON THE GROUND





