

FORD RANGER PX UTE & CAB CHASSIS 09/11 – ON

PART NO.

UNT297

1. On the drivers side underneath the vehicle at the rear you will find a 6 way connection point leading to the rear tail lights.
2. Disconnect the 6 way tail light harness connectors at the rear.
3. On the wiring harness you will find a label marked RHS. Connect the 6 way wiring harness connectors to the corresponding connectors.
4. Route the remainder of the wiring harness across the to the passenger side. Using cable ties secure the wiring harness to the vehicle or an existing cable.
5. Repeat steps 1,2 & 3 for the LHS.
6. Securely mount the ECU unit as high up under the body or tray as possible.
7. Route the long black power lead to the battery at the front of the vehicle. Secure the power lead along the way with cable ties, to keep the lead from hanging down.
8. When connecting the power wire to the power source please ensure that the 15amp in line fuse holder is close to the power supply
9. Fit the required socket to the wiring harness and mount the plug to the desired position
10. Insert the 15 amp fuse supplied into the fuse holder
11. Connect your towbar wiring test board and test functions

