



INSTALLATION GUIDE

**IMPORTANT: MUST BE USED IN CONJUNCTION
WITH AN IRONMAN 4X4 BULL BAR**

IRP057

HOLDEN COLORADO 2016+



- Ironman 4x4 Recovery Points fit to the chassis
- It will take about 20 mins to install
- Below is a list of required tools for installing your Ironman 4x4 Recovery Points:
 - **13, 17, and 19mm socket**

IMPORTANT: Recovery Point installations should only be done by a qualified person and it is the responsibility of this person to ensure correct fitment.


1. Before installation check recovery points are compatible with your vehicle.

2. Remove the front factory under trays.

3. Remove the 10 x bolts holding the two factory tie down points, and disregard




4. Lift recovery point into position. Using 4 x M10 bolts, spring washers, and flat washers, loosely attach recovery points using the holes illustrated.



5. Feed the 2 x nut plates with the short wire into the radiator support mount to pick up the front inner holes use 2 x M12 bolts, spring washers and flat washers



6. Locate the hole in-between the rear of the recovery point next to the electric steering



7. Feed the 2 x nut plates with the long wire through the hole, to pick up each of the centre holes of the recovery point using M12 bolts, spring washers and flat washers



8. Use the 2 x M10 bolts, spring washers, and flat washers in the remaining 2 holes of the recovery point



9. Tighten all bolts

10. Cut all excess wire off

11. Refit all the factory under trays

