



# INSTALLATION GUIDE

## IRP059

TO MITSUBISHI PAJERO SPORT 11/2016+  
(GLS, GLX AND EXCEED Models)



- Ironman 4x4 Recovery Points fit to the chassis
- It will take about 45 mins to install, or 10 mins if installed with fitment of bull bar
- Below is a list of some required tools for installing your Ironman 4x4 Recovery Points:
  - **Socket (13, 17 and 19mm)**
  - **Spanner (19mm)**


DATE OF ISSUE: 071118

**IMPORTANT: Must be used in conjunction with an Ironman 4x4 Bull Bar**

**IMPORTANT:** Recovery Point installations should only be done by a qualified person and it's the responsibility of this person to ensure correct fitment.

1. Before installation check recovery points are compatible with your vehicle.

2. One side at a time, remove all fasteners from the chassis strengthening bracket.



3. Align recovery point to chassis.

NOTE: On passenger side, place the spacers between the recovery point and chassis.



4. Re-use the U-bolt from the strengthening bracket and leave loose.

On passenger side use the U-Bolt supplied.



5. Re-use the long bolt, washers and nut removed from bracket, then pass through the chassis.



6. Place the spacer plate on the other side of the factory tie down point and use the supplied 10.9 tensile bolt, 2 x flat washers, spring washer and nut.



7. Use the supplied 10.9 bolts in the remaining holes.

Note: On the passenger side, the top rear bolt will not be required.



8. On the centre plate, trim 50 x 10mm off the corner of the driver's side as shown.

Re-install all under trays.

